

Be sure to read all instructions before starting installation.

Care Instructions

Clean with a soft cloth. Do not use abrasive cleaning agents, solvents, or polishes as they may damage the finish.

Estimated Assembly Time: 30 minutes

Need help? If you are missing parts, do not return the product to the place of purchase. Call 1-877-695-8268.

Tools Needed (not included)

- Drill with 3/16 in. drill bit
- Phillips screwdriver
- Level (recommended)

Holdback Installation

1. Using holdback as a guide, locate desired position and mark on wall for mounting screws.
2. Set aside and drill pilot holes into wall with 3/16 in. drill bit. Insert wall anchors. (Wall anchors may not be necessary for all applications.)
3. Attach holdback to wall using screws provided.
4. Repeat steps for additional holdbacks.

