

WOOD DOUBLE BRACKET INSTALLATION

BE SURE TO READ ALL INSTRUCTIONS PRIOR TO STARTING INSTALLATION.

Estimated installation time - 30 minutes

Tools Needed (not included)

- Drill with 3/16 in. drill bit
- Phillips screwdriver
- Level (recommended)

These brackets are designed to be used with wood drapery hardware poles.

Bracket installation

Double bracket installation

1. Using bracket as a guide, find location on wall and mark. Use level if necessary.
2. Drill pilot holes in wall with 3/16 in. bit.
3. Insert wall anchors and install top screw. Do not tighten flush to wall. Leave 1/8 in. of screw exposed to hang bracket.
4. Hang bracket and insert bottom screw to secure to wall.
5. Repeat for additional brackets.

Pole installation (not included)

1. Place draperies on poles and hang on brackets.
2. Hold pole and bracket with one hand and lightly apply downward pressure while installing set screw through hole on bottom of bracket.
3. Repeat for additional brackets.

Care instructions

Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes as they may damage the finish.

Need help? If you are missing parts, do not return the product to the place of purchase. Call 1-877-695-8268.

