

BE SURE TO READ ALL INSTRUCTIONS PRIOR TO STARTING INSTALLATION.

Estimated installation time - 10 minutes

#### Sconce installation

1. Using sconce as a guide, find location on wall and mark. Use level if necessary.
2. Drill pilot holes in wall with 3/16 in. bit.
3. Insert wall anchors and install screws. Do not tighten flush to wall. Leave 1/8 in. of screws exposed to hang sconces.
4. Repeat for additional sconces.

#### Care instructions

Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes as they may damage the finish.

Need help? If you are missing parts, do not return the product to the place of purchase. Call 1-877-695-8268.

