

BE SURE TO READ ALL INSTRUCTIONS BEFORE STARTING INSTALLATION

Care Instructions:

Clean with a soft cloth. Do not use abrasive cleaning agents, solvents, or polishes as they may damage the finish.

Estimated Assembly Time: Approximately 30 minutes

Tools Needed (not included):

Drill with $\frac{3}{16}$ in drill bit, Phillips screwdriver, Level (recommended), Hammer

Bracket Installation (Diagram 1):

1. Find desired position, and mark on wall. Drill pilot hole using $\frac{3}{16}$ in drill bit and use hammer to insert wall anchor. (Wall anchors may not be necessary for all applications.)
2. Attach bracket to wall using screws provided.
3. Repeat steps 1 to 3 for additional bracket.

Rod and Drapery Installation:

1. Extend telescopic rod slightly (Diagram 2).
2. Feed drapery panels or rings (not included) onto rod. Extend rod to desired length and hang rod in holder on brackets. Screw finials onto rod (Diagram 3).
3. Tighten all set screws on brackets to lock rod in place (Diagram 4). If rings are used, attach drapery panels to rings.

ASEGÚRESE DE LEER TODAS LAS INSTRUCCIONES ANTES DE COMENZAR LA INSTALACIÓN

Instrucciones para el cuidado:

Limpie con un paño suave. No utilice agentes limpiadores abrasivos, disolventes ni pulimentos ya que podrían dañar el acabado.

Tiempo estimado de ensamblaje: Aproximadamente 30 minutos

Herramientas necesarias (no incluidas):

Taladro con broca de $\frac{3}{16}$ " , Destornillador de estrella, Nivel (recomendado), Martillo

Instalación de los soportes (diagrama 1):

1. Identifique la posición deseada y márkela en la pared. Perfore el orificio guía utilizando un taladro con broca de $\frac{3}{16}$ " e inserte el ancla de pared utilizando un martillo. (Para algunas aplicaciones puede ser que no necesite anclas de pared.)
2. Fije el soporte a la pared utilizando los tornillos que se proporcionan.
3. Repita los pasos 1 al 3 para el soporte adicional.

Instalación de la varilla y las cortinas:

1. Extienda ligeramente la varilla telescópica (diagrama 2).
2. Introduzca los paneles de cortina o los aros (no incluidas) en a varilla. Extienda la varilla al largo deseado y colóquela en el sujetador de los soportes. Fije los remates decorativo para sostener la varilla en su lugar. (diagrama 3)
3. Apriete todos los tornillos de fijación de los soportes para fijar la varilla en su lugar (diagrama 4). Si utiliza aros, fije los paneles de cortina a los aros.

